




CEI 79-2
EN 50131-3
EN 50131-6
CEB T01



Live Smart with Ness SmartLiving

Ness SmartLiving
Anti-intrusion Control Panels & Security Systems

SHORT FORM USER & INSTALLER MANUAL

REV 1



Quick Guide for everyday
User operations



Quick Guide for basic
installation programming

Instructions based on the nCode matrix LCD keypad



Innovative Electronic Solutions



www.nesscorporation.com

National Customer Service Centre
Ph: 1300 551 991
customerservice@ness.com.au




Ness Smartliving
Short Form User & Installer Manual

Document Part No: 890-033


All rights reserved. No part of this publication may be reproduced, transmitted or stored in a retrieval system in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Ness.

Ness reserves the right to make changes to features and specifications at any time without prior notification in the interest of ongoing product development and improvement.


© Ness Corporation Pty Ltd ABN 28 069 984 372




LED Indicators



Keypad Keys



The 4 line LCD matrix display provides system information in an easy to read format.



Line 1

In disarmed and armed mode, shows the time and date. If there has been a recent alarm the event is shown, eg. Panel T03

The time display returns next time you arm/disarm.

Line 2

Indicates the armed status of the partitions and several other system events.


In the example shown on this keypad **D-----** indicates that partition 1 is disarmed and partitions 2-5 are not assigned to this keypad.

T flashing indicates a telephone line fault (in this case the phone line is not connected).

Line 3, 4

The bottom lines display function icons which are actioned using the shortcut keys F1–F4.

Press to scroll the display sideways and show up to 12 function icons.



Press an F key for at least 1 sec to select a function

ICON	F key	Description
		QUICK ARM. A fast and easy way to arm partition 1 without using a code.
		ZONE BYPASS MENU. Allows you to temporarily Bypass (Exclude) selected zones. This menu will ask for your user code)
		STOP ALARMS. Resets any outputs triggered by an alarm. (This menu will ask for your user code)
		ARM STAY MODE (Home Mode). Arms perimeter zones. (This menu will ask for your user code)
Press to scroll the display		
		EVENT LOG. View the log of arm/disarm events, zone bypass, system alarms with time and date stamps. Scroll using up and down keys
		ALARM LOG. View the log of alarm and tamper events with time and date stamps. Scroll using up and down keys
		VIEW FAULTS. View current system faults (eg, low battery, line fail). Scroll using up and down keys
		CLEAR MEMORY. Deletes the log of alarm, tamper, system alarm events. Does not delete the arm/disarm event log. Clear Memory also stops the siren outputs if running. (This menu will ask for your user code)


ICON	F key	Description
Press  to scroll the display		
	F1	OUTPUT MENU. Control the relay outputs and terminals programmed as outputs. Turn outputs on and off using the star and hash keys  *  # (This menu will ask for your user code)
**#3	F2	CHANGE PIN Menu. Change user codes. (This menu will ask for your user code)
	F3	CLOCK Menu. Change the time and date. (This menu will ask for your user code)
	F4	ARM/DISARM Menu. Allows you to arm/disarm partitions with a choice of arming modes. (This menu will ask for your user code)

KEYPAD BEEPER	DESCRIPTION
Single beep 	Any key press
8 beeps repeated 	During Entry Delay
3 beeps repeated 	During Exit Delay
4 fast beeps repeated 	During the last 40 sec of Exit Delay
1 beep repeated 	Pre-arm Timer running
Continuous beep 	Activation of the output on terminal T1 on the keypad

Default user code 1:
0001

Before you start.

- Red LED should be off (panel is disarmed)
- Yellow LED should be off (no system alarms)
- Blue LED should be on (all zones sealed)
- Green LED should be on (power is ok)



Quick Arming

This quick and easy one-step method arms partition 1 in Away mode.

1. Press and hold the **F1** shortcut key

You will see:



The Red LED will turn on.



A shows that partition 1 is armed in Away mode

You will hear: Beeps during exit delay

Arming by Code

Another easy method to arm partition 1 in Away mode. Just enter your user code.

1. Enter your user code.

You will see:



The Red LED will turn on.



A shows that partition 1 is armed in Away mode

You will hear: Beeps during exit delay

Arming by Menu

This method gives you full control over the arming/disarming process and lets you choose the partition and type of arming.


1. Press  twice to scroll the display to the third icon screen.



2. Press **F4** to select the arming menu.




3. Enter your user code.



4. Use the   keys to choose an action for partition 1 then press **OK**

- N = none
- A = Away
- S = Stay
- I = Instant
- D = Disarm



Use the   keys to select another partition.

For example if you choose Away mode.

You will see:



The Red LED will turn on.



A shows that partition 1 is armed in Away mode

You will hear: Beeps during exit delay


To disarm, simply enter your code.

1. Enter your user code.

You will see:



The Red LED will turn off.



D shows that partition 1 is disarmed


If there has been an alarm the Red LED and D on the display will flash until the next time you arm or until the memory is cleared.

Handy Hint.

For example, you can use the Stop Alarms shortcut to silence the sirens while leaving the system armed.

The Stop Alarms shortcut lets you silence the sirens without affecting the armed/disarmed status of the panel. Stop Alarms turns off any outputs activated by zone, tamper and system alarms.

1. Press **F3** to select Stop Alarms.



2. Enter your user code.



You will hear: Any sirens running will stop.

FACTORY DEFAULTS

User code 1: 0001
 User code 2: 0002
 up to...
 User code 30: 0030

INFO

Program up to 30 user codes.

NOTES


Use the Change PIN menu to change users codes.

User codes must first be enabled in installer program mode.

Changing User Codes/PIN


SmartLiving 505 & 515 control panels have 30 user codes which can be easily changed from the keypad.

1. Press  twice to scroll the display to the third icon screen.




2. Press **F2** to select the Change PIN menu.

3. Enter your user code.



4. Use the   keys to choose a user code then press **OK**



5. Enter a new PIN then press **OK**



6. Enter the new PIN again then press **OK**



To enter installation program mode

```
Type in code
****--
```

Enter your Installer Code then
press **OK**

The default installer code is 9999.

To exit installation program mode

```
EXIT? OK = YES
```

Press ESC until you see the exit
message then press **OK**

Once you exit program mode the keypad
will blank out for a few seconds while the
panel rescans all bus devices.

Set the maintenance jumper to the SERV position during programming.

In this mode:

- The keypad display will show the bus address of the keypad.
- Bus devices will be auto-enrolled
- Outputs will be inactive.

Set the jumper to SERV during initial programming of the system.



SERV

Remember to return the jumper to the RUN position when you're done.



RUN

FACTORY DEFAULTS

Installer code 1: 9999
Exit Delay: 30 sec
Entry Delay: 30 sec

NOTES

Use the   keys to scroll up and down.

The panel must be in the disarmed state to enter programming.

Use the Installer programming menu for easy programming of panel options via keypad.


1. Enter your Installer Code then press 




2. Scroll to **Partitions** then press 



3. Choose Partition 001 then press 




4. Choose Exit Time or Entry Time then press 



5. Enter a new exit time, eg, '040' then press 

Use the   keys to move the cursor.

Use the   keys to select Seconds or Minutes.



FACTORY DEFAULTS

Siren timer (relay output): 3 min
Strobe timer (Output1): 125 min
Internal siren timer (Output2): 3 min

NOTES


Use the   keys to scroll up and down.

The panel must be in the disarmed state to enter programming.

1. Enter your Installer Code then press 



2. Scroll to **Outputs** then press 



3. Choose RELAY, Output 1 or Output 2 then press 




4. Choose Monostable Time then press 



5. Enter a new exit time, eg, '004' then press 

Use the   keys to move the cursor.

Use the   keys to select Seconds or Minutes.



Program a Telephone Number & Account Number

FACTORY DEFAULTS

Installer code 1: 9999
 Telephone Numbers: none
 Account Numbers: 0000

NOTES

• Use the   keys to scroll up and down.

• The panel must be in the disarmed state to enter programming.

• Telephone numbers can be up to 20 digits long.


• Alarms can be reported to a central station via Contact ID or to mobile phone numbers to report alarms by voice.*

*The optional 106-409 SmartLogos30M Voice Module is required for voice monitoring.


• HINT.
 Telephone numbers 003 and onwards are pre-configured for Voice dialling. ie, open/close reports are disabled and most system alarms are not sent.

- Program up to 15 telephone numbers for alarm reporting back-to-base, voice reporting or SMS alarm reporting.
- Program the reporting options for each telephone number
- Program your 4 digit account number for back-to-base reporting


1. Enter your Installer Code then press 



2. Scroll to Telephone then press 




3. Choose Select Number then press 




4. Choose NUMBER 001 then press 


Telephone Numbers 001 & 002 are pre-configured for central station monitoring.



5. Choose Number then press 




6. Enter your central station telephone number then press 



7. Choose Account Code then press 



8. Enter your 4 digit account number then press 



Program a Telephone Number, Account Number, alarm type

FACTORY DEFAULTS

Installer code 1: 9999
 Telephone Numbers: none
 Account Numbers: 0000

NOTES

- Use the   keys to scroll up and down.
- The panel must be in the disarmed state to enter programming.
- Telephone numbers can be up to 20 digits long.
- Telephone numbers can be up to 20 digits long.
- A telephone number can be a central station number for back-to-base monitoring or a mobile phone number to report alarms by voice.*

*The optional 106-409 SmartLogos30M Voice Module is required for voice monitoring.


- HINT.
 Telephone numbers 003 to 015 are pre-configured for Voice dialling. ie, open/close reports are disabled and most system alarms are not sent.

Program up to 13 telephone numbers for alarm reporting by voice call.*


1. Enter your Installer Code then press 



2. Scroll to Telephone then press 




3. Choose Select Number then press 



4. Choose NUMBER 003 then press 


Telephone Numbers 003 to 015 are pre-configured for voice monitoring.



5. Choose Number then press 



6. Enter the phone number to be called then press 




7. Choose Type then press 



8. Choose Voice call then press 

'Voice call' should already be selected.



Enrolling a wireless PIR

FACTORY DEFAULTS

No wireless devices enabled.

NOTES

• SmartLiving 505 panel supports up to 5 wireless PIRs, reed switches or smoke detectors and up to 50 wireless keyfobs.

• SmartLiving 515 panel supports up to 15 wireless PIRs, reed switches or smoke detectors and up to 50 wireless keyfobs.

• Operation of the keypad numeric keys when programming Terminals.

1 sets the terminal as an INPUT (I)

2 sets the terminal as an OUTPUT (O)

3 sets the terminal as a TWO WAY SUPERVISED OUTPUT (T)

4 sets the terminal as a DOUBLE ZONE (D)


5 sets the terminal as UNUSED (-)

6 sets the terminal as WIRELESS

Use  keys to scroll up and down.


Use  keys to move the cursor.

- Set the bus address on your transceiver to address 2 (Switch 8 on). It will be seen by the system as Expander 2.




Set the panel's maintenance link in SERV position to auto-enrol the transceiver. 

- In Installation program mode, scroll to Terminals then press **OK**




- Scroll to Expander 2 then press **6** to toggle the expander's terminals to Wireless. All the terminals on this expander are now reserved for wireless.




THIS STEP IS REQUIRED FOR 505 PANELS ONLY


- For 505 panels only.² Firstly disable a terminal on the main board to free up a terminal on the expander (transceiver). Scroll to 'Panel' then scroll across to terminal 5 and press **5** to disable the terminal.




- Enrolling the radio PIR. Go to Programming > Zones then press **OK**



Scroll down to Expander 02 Terminal 01 then press **OK**



Choose Wireless then press **OK**



Choose Enroll Sensor then press **OK**



Choose Infrared Sensor then press **OK**



Press the Enroll button inside the PIR



The keypad will beep once to indicate successful enrolment.

